

<https://www.techfinder.in>

Digital watch recorder USER'S MANUAL

(Recording, camera, mobile detection, infrared night vision Watch)


D watch

<https://www.techfinder.in>


High definition

CAMERA WATCH


<https://www.techfinder.in>



— . Profile



II. Indicating lamp status:



- 1、 the red light / green light indicates: the 2 point of the watch clock;
- 2、 blue light indication: 4 points of the clock of the watch.
- 3、 the blue light long light: Video standby state;
- 4、 the green light long light: indicates the recording standby state;
- 5、 blue light / green light two lights at the same time: to show that the camera standby state;
- 6、 charging when the red light long light: indicates the state of charge; out of full.
- 7、 the memory is not enough (no memory card): blue light flash 5S after shutdown.
- 8、 the power shortage: Green light slow flash or automatic shutdown.


三. First operation procedure

description: <https://www.techfinder.in>

1. Card watch installed memory card (with built-in memory can omit this step): counter clockwise rotation to open the bottom of the watch cover, correctly remove the battery after open the memory card slot cover, GM will TF card installed in the card slot cover, and then remove the battery properly installed good along the clockwise to tighten the watch bottom cover can be used.
- 2 Local Format Memory Card (when formatting with large capacity memory card above 64GB)

First, press and hold the format button to connect the data cable to the charger or the computer USB interface, this time the blue lights flashing is said to be formatted, when the blue light is bright when the format is completed. Because the memory card format is not right or the file is damaged, it can not be operated, please format it on the machine before it can be used normally.

四. Functional operation instructions:




<https://www.techfinder.in>

<https://www.techfinder.in>

<https://www.techfinder.in>


<https://www.techfinder.in>



<https://www.techfinder.in>

<https://www.techfinder.in>

五. Modified time / time watermarking / video resolution operation instructions:



<https://www.techfinder.in>

Modify the Time.txt electronic documents on the computer U disk, in which the work time / time watermark / resolution were modified and saved, re boot once you can modify the set time.

Setdescription: 2017.05.01-01:01:01-Y-1

2019.01.01-01:01:01-Y-1——Modified for current time

Y——File time watermark display

N——No time watermark display


1——1080P resolving power: 1920*1088

2——720P resolving power: 1280*720

3——VGA resolving power: 640*480

<https://www.techfinder.in>

六、Reset function instructions:



This machine for the combination of key reset, you must press the switch key and boot key, when the machine fails or crash, you can press the two buttons to reset the shutdown.

<https://www.techfinder.in>

<https://www.techfinder.in>

七、Charging / video link to the PC/ PC camera operating instructions:

<https://www.techfinder.in>

<https://www.techfinder.in>

USB/charging
connection port



<https://www.techfinder.in>

<https://www.techfinder.in>

- 1、 open USB waterproof funeral gifts on the watch, the data line and the power adapter or mobile power connection to use while charging, charging the red light, filled with red light.
- 2、 to ensure that the machine is in a shutdown state, the data line and the computer PC machine, you can enter the U disk operation, the battery can also be charged at this time.
- 3、 the machine is in standby state, and the data line is connected with the computer PC machine, the device automatically install the driver, the computer will be installed after the completion of the video device can be turned on the camera.

<https://www.techfinder.in>

<https://www.techfinder.in>

八、problem resolution: <https://www.techfinder.in>

Item	Parameter
memory	TF (8GB-256GB) Format FAT32 Configuration File Size 32KB
Video format	AVI (time watermark can be set to display / do not display Y/N)
Photo format	JPG https://www.techfinder.in
Audio format	WAV
Video resolution	1920 x 1088 /1280*720/640*480 Set their own (1/2/3)
Photo resolution	4032 x 2912
Frame rate	About 30 frames per second
Mini illumination	10Lux (infrared light on opening night vision)
IR Switch	Automatic https://www.techfinder.in
USB type	Mini 8Pin/USB2.0
Supporting system	Windows me/2000/xp/Win7/2003/vista; Mac os10.4; Linux above

<https://www.techfinder.in>

九、Maintenance:

<https://www.techfinder.in>

Battery: If the watch is not in use for a long time, please have it fully charged before using. For safety, do not put this watch too close to fireplace or overheated spot.

Operating temperature: 0—40° C. For the extension of battery life, it is better to use it in room temperature.

<https://www.techfinder.in>

Operating humidity: 20% -80%. This product does not have water resistance function (only waterproof when MIC2 is used). So it can not work in the very humid environment or under water.

Lens: Do not expose the camera lens directly to strong light such as sun light so as to avoid damage to optical devices.

<https://www.techfinder.in>

Cleaning: Always use dry cloth to clean up the glass before doing recording. The watch has a transparent cover on the glass for protection, please remove it before using the camera.

<https://www.techfinder.in>